



# Height of potential fall

Height of fall is **not** the height of your balustrade.

Please see the diagram showing height of fall.

If your system is offering protection from a potential fall 600mm or higher you must have a legally compliant system.

Under 600mm this is considered more a partition and you do not need a fully compliant system.

It is also important to consider how high above sea level your system is as anything over 8m should always be considered a high wind load and this can change glass specification and anchoring solutions.

The measurement required is highlighted in red as potential fall height in mm

